

Industrial Electronic Devices

User Manual

Revision 2.201 English

Modbus Slave / Modbus TCP Master - Converter

(Order Code: HD67510-A1, HD67510-A1-422, HD67510-B2, HD67510-Slim-232, HD67510-Slim-485)

For Website information:

www.adfweb.com?Product=HD67510

For Price information:

www.adfweb.com?Price=HD67510-A1 www.adfweb.com?Price=HD67510-A1-422 www.adfweb.com?Price=HD67510-B2 www.adfweb.com?Price=HD67510-Slim-232 www.adfweb.com?Price=HD67510-Slim-485

Benefits and Main Features:

- 32mm Rail DIN mount
- Wide supply input range
- Triple electrical isolation
- Temperature range: -40°C/+85°C (-40°F/+185°F)



User Manual

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 1 of 38

For others products, see also the following links:

RS232 / RS485 / USB / Ethernet

www.adfweb.com?Product=HD67118 (RS232 / RS485 - Converter)
www.adfweb.com?Product=HD67119 (USB / RS485 - Converter)
www.adfweb.com?Product=HD67038 (RS485 / RS232 / Ethernet - Converter)

CAN / CANopen / Modbus / Modbus TCP

www.adfweb.com?Product=HD67001(CANopen / Modbus Master - Converter)www.adfweb.com?Product=HD67502(CANopen / Modbus Slave - Converter)www.adfweb.com?Product=HD67011(CAN / Modbus Master - Converter)www.adfweb.com?Product=HD67012(CAN / Modbus Slave - Converter)www.adfweb.com?Product=HD67514(CAN / Modbus Slave - Converter)www.adfweb.com?Product=HD67515(CAN / Modbus TCP Master - Converter)www.adfweb.com?Product=HD67515(CAN / Modbus TCP Slave - Converter)

Modbus TCP Slave / Modbus Master - Converter

www.adfweb.com?Product=HD67507
www.adfweb.com?Product=HD67508

Do you have your customer protocol? Then go to: www.adfweb.com?Product=HD67003

Do you need to choose a device? Do you want help? www.adfweb.com?Cmd=helpme

ADFweb.com S.r.l.



Industrial Electronic Devices

INDEX:

	Page
INDEX	2
UPDATED DOCUMENTATION	2
REVISION LIST	2
WARNING	2
TRADEMARKS	2
SECURITY ALERT	3
EXAMPLES OF CONNECTION	4
CONNECTION SCHEME	5
CHARACTERISTICS	10
CONFIGURATION	10
POWER SUPPLY	11
FUNCTION MODES	12
LEDS (for HD67510-A1 and HD67510-B2)	13
LEDS (for HD67510-Slim-xxx)	14
ETHERNET	15
RS232	15
RS485	16
RS422	17
USE OF COMPOSITOR SW67510	18
NEW CONFIGURATION / OPEN CONFIGURATION	19
SOFTWARE OPTIONS	20
SET COMMUNICATION	21
UPDATE VIA UDP	29
MECHANICAL DIMENSIONS	31
ORDERING INFORMATIONS	35
ACCESSORIES	36
DISCLAIMER	37
OTHER REGULATIONS AND STANDARDS	37
WARRANTIES AND TECHNICAL SUPPORT	38
RETURN POLICY	38

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 2 of 38

UPDATED DOCUMENTATION:

Dear customer, we thank you for your attention and we remind you that you need to check that the following document is:

- Updated
- Related to the product you own

To obtain the most recently updated document, note the "document code" that appears at the top right-hand corner of each page of this document.

With this "Document Code" go to web page <u>www.adfweb.com/download/</u> and search for the corresponding code on the page. Click on the proper "Document Code" and download the updates.

REVISION LIST:

Revision	Date	Author	Chapter	Description
2.100	10/07/2019	Ff	All	Revision
2.200	10/01/2023	Ff	All	Added Slim version
2.201	15/04/2025	Ln	All	New design

WARNING:

ADFweb.com reserves the right to change information in this manual about our product without warning.

ADFweb.com is not responsible for any error this manual may contain.

TRADEMARKS:

All trademarks mentioned in this document belong to their respective owners.



Document code: MN67510_ENG Revision 2.201 Page 3 of 38

SECURITY ALERT:

GENERAL INFORMATION

To ensure safe operation, the device must be operated according to the instructions in the manual. When using the device, legal and safety regulation are required for each individual application. The same applies also when using accessories.

INTENDED USE

Machines and systems must be designed so the faulty conditions do not lead to a dangerous situation for the operator (i.e. independent limit switches, mechanical interlocks, etc.).

QUALIFIED PERSONNEL

The device can be used only by qualified personnel, strictly in accordance with the specifications.

Qualified personnel are persons who are familiar with the installation, assembly, commissioning and operation of this equipment and who have appropriate qualifications for their job.

RESIDUAL RISKS

The device is state-of-the-art and is safe. The instruments can represent a potential hazard if they are inappropriately installed and operated by untrained personnel. These instructions refer to residual risks with the following symbol:

This symbol indicates that non-observance of the safety instructions is a danger for people that could lead to serious injury or death and / or the possibility of damage.

CE CONFORMITY

The declaration is made by our company. You can send an email to <u>support@adfweb.com</u> or give us a call if you need it.



Document code: MN67510_ENG Revision 2.201 Page 4 of 38

EXAMPLES OF CONNECTION:



HD67510-A1





Document code: MN67510_ENG Revision 2.201 Page 5 of 38

CONNECTION SCHEME:







Document code: MN67510_ENG Revision 2.201 Page 6 of 38



Figure 1b: Connection scheme for HD67510-A1-422



Document code: MN67510_ENG Revision 2.201 Page 7 of 38

Industrial Electronic Devices



Figure 1c: Connection scheme for HD67510-B2

AD web

Industrial Electronic Devices

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 8 of 38



Figure 1d: Connection scheme for HD67510-Slim-232

ADF web

Industrial Electronic Devices

Document code: MN67510_ENG Revision 2.201 Page 9 of 38



Figure 1e: Connection scheme for HD67510-Slim-485

Document code: MN67510_ENG Revision 2.201 Page 10 of 38



Industrial Electronic Devices

CHARACTERISTICS:

The HD67510 converters are a Modbus Slave / Modbus TCP Master – Converter.

It allows for the following characteristics:

- ✤ Triple isolation between Serial Power Supply, Serial Ethernet, Power Supply Ethernet.
- Ethernet 10Base-T / 100Base-T, autosensing for Modbus TCP ;
- Mountable on 35mm Rail DIN;
- Wide power supply input range: 8...24V AC or 12...35V DC;
- ✤ Wide temperature range: -40°C / +85°C [-40°F / +185°F].

CONFIGURATION:

You need Compositor SW67510 software on your PC in order to perform the following:

- Define the parameters of Modbus TCP line;
- Define the parameters of Serial Modbus line;
- Update the device.



Document code: MN67510_ENG Revision 2.201 Page 11 of 38

POWER SUPPLY:

The devices can be powered at 8...24V AC and 12...35V DC. For more details see the two tables below.

VAC	\sim	VDC	
Vmin	Vmin Vmax		Vmax
8V	24V	12V	35V

Consumption at 24V DC:

Device	Consumption [W/VA]
HD67510-A1-xxx	3.5
HD67510-B2	3.5
HD67510-Slim-xxx	3.5





Document code: MN67510_ENG Revision 2.201 Page 12 of 38

FUNCTION MODES:

The device has got two function modes depending on the position of the 'Dip-Switch A'.

- ✤ With 'Dip1 of Dip-Switch A' at "OFF" position, is used for the normal working of the device.
- ✤ With 'Dip1 of Dip-Switch A' at "ON" position, is used for uploading the Project and/or Firmware.

For the operations to follow for the updating, see 'UPDATE DEVICE' section.

According to the functioning mode, the LEDs will have specific functions, see 'LEDS' section.





Document code: MN67510_ENG Revision 2.201 Page 13 of 38

LEDS (for HD67510-A1 and HD67510-B2):

The devices has got four (five for HD67510-B2) LEDs that are used to give information of the functioning status. The various meanings of the LEDs are described in the table below.

LED	Normal Mode	Boot Mode	
1: Device state	Device state Blinks slowly (~1Hz) Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in p		
2: Ethernet Link	ON: Ethernet cable connected OFF: Ethernet cable disconnected	ON: Ethernet cable connected OFF: Ethernet cable disconnected	
3: Serial comm.	Blinks when are received Modbus response frames (RS232/RS485)	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress	
4: Modbus TCP comm.	Blinks when are received Modbus TCP request frames	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress	
5: Not used (present only on HD67510-B2)	OFF	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress	





Document code: MN67510_ENG Revision 2.201 Page 14 of 38

LEDS (for HD67510-Slim-xxx):

The devices has got five LEDs that are used to give information of the functioning status. The various meanings of the LEDs are described in the table below.

LED	Normal Mode	Boot Mode
1: Device state	Blinks slowly (~1Hz)	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
2: Modbus communication	Blinks when are received Modbus response frames (RS232/RS485)	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
4: Modbus TCP communication	Blinks when are received Modbus TCP request frames	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
4: Not used	OFF	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
5: Ethernet Link	ON: Ethernet cable connected OFF: Ethernet cable disconnected	ON: Ethernet cable connected OFF: Ethernet cable disconnected





Document code: MN67510_ENG Revision 2.201 Page 15 of 38

ETHERNET:

The Ethernet connection must be made using Connector5 of HD67510-A1/HD67510-B2 or Connector3 of the HD67510-Slim with at least a Category 5E cable. The maximum length of the cable should not exceed 100m. The cable has to conform to the T568 norms relative to connections in cat.5 up to 100 Mbps. To connect the device to a Hub/Switch the use of a straight cable is recommended. To connect the device to a PC/PLC/other the use of a cross cable is recommended.





RS232:

The connection from RS232 socket to a serial port (example one from a personal computer) must be made with a Null Modem cable (a serial cable where the pins 2 and 3 are crossed).

It is recommended that the RS232 cable not exceed 15 meters.

The device is provided with a D-sub connector type DE-9 Male (also called DB-9). The cable must use a DE-9 Female connector.

The serial port is used for programming the device and for Modbus communication.





Document code: MN67510_ENG Revision 2.201 Page 16 of 38

RS485:

To terminate the RS485 line with a 120Ω resistor, it is necessary to put dip 1 ON, like in figure. The maximum length of the cable should be 1200m (4000 feet).



Here some codes of cables:

- Belden: p/n 8132 2x 28AWG stranded twisted pairs conductor + foil shield + braid shield;
- Belden p/n 82842 2x 24AWG stranded twisted pairs conductor + foil shield + braid shield;
- Tasker: p/n C521 1x 24AWG twisted pair conductor + foil shield + braid shield;
- ✤ Tasker: p/n C522 2x 24AWG twisted pairs conductor + foil shield + braid shield.



Document code: MN67510_ENG Revision 2.201 Page 17 of 38

RS422:

For terminate the RS422 line with a 120Ω resistor it is necessary to put ON dip 1 for T line and/or put ON dip 2 for R line, like in figure.



The maximum length of the cable should be 1200m (4000 feet).



Document code: MN67510_ENG Revision 2.201 Page 18 of 38

USE OF COMPOSITOR SW67510:

To configure the Converter, use the available software that runs with Windows called SW67510. It is downloadable on the site <u>www.adfweb.com</u> and its operation is described in this document. *(This manual is referenced to the last version of the software present on our web site)*. The software works with MSWindows (XP, Vista, Seven, 8, 10 or 11; 32/64bit).

When launching the SW67510, the window on the right appears (Fig. 2).

Mote:

It is necessary to have installed .Net Framework 4.

SW	com - Configurator SW67510 - Mod 67510	bus Slave / Modbus TCP Master	×
Modbus 9 Begin	Slave / Modbus TCP Master - Opened Configuration of the C Example1	Converter :	
Step 1	New Configuration	Dpen Configuration	
Step 2	Set Communication		
Step 3	Translate Table		
Step 4	🔀 Update via UDP	💥 Update via Serial	www.ADFweb.com

Figure 2: Main window for SW67510



NEW CONFIGURATION / OPEN CONFIGURATION:

The **"New Configuration**" button creates the folder which contains the entire device's configuration.



A device's configuration can also be imported or exported:

- To clone the configurations of a Programmable "Modbus Slave / Modbus TCP Master -Converter" in order to configure another device in the same manner, it is necessary to maintain the folder and all its contents;
- To clone a project in order to obtain a different version of the project, it is sufficient to duplicate the project folder with another name and open the new folder with the button "Open Configuration".

🟙 Open Configuration	—		×
SW67510 Open an Existing Configuration List of Avaliable Configurations			
Example2 Example3			
с ок		Canc	el

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 19 of 38



Document code: MN67510_ENG Revision 2.201 Page 20 of 38

SOFTWARE OPTIONS:

By pressing the "**Settings**" () button there is the possibility to change the language of the software and check the updatings for the compositor.

In	the	section	"Language"	it	is	possible	to	change	the	language	of	the
sof	twar	e.										

🛗 Software Options 🛛 🕹 🗙
SW67510 Software Options
Enable Internet Connection Check Software Update at Start of Program
Check Available Update
OK Cancel

_	Web Software	Options ×
e	Software	67510
	Language	Connection Options
	Selected	Language : English
		Deutsch
		English
		Page 1 / 1
	V	OK Cancel

In the section "Connection Options", it is possible to check if there are some updatings of the software compositor in ADFweb.com website. Checking the option "**Check Software Update at Start of Program**", the SW67510 check automatically if there are updatings when it is launched.

ADFweb.com S.r.l.



SET COMMUNICATION:

By Pressing the "**Set Communication**" button from the main window for SW67510 (Fig. 2) the window "Set Communication" appears (Fig. 3).

The window is divided in different sections in order to define the different parameters of the converter:

- Operation Mode
- Modbus Slave
- ✤ Modbus TCP Master

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 21 of 38

🟙 Set Communication		×
SW67510 Set Communication Setting		
1. Operation Mode		Ð
2. Modbus Slave		÷
3. Modbus TCP Master		Ŧ
	🔶 ок	Cancel

Figure 3a: "Set Communication" window



OPERATION MODE:

This section is used to define the working mode of MQTT side of the converter. It is possible to define:

Normal Mode (with Translate Table): the converter can be seen like a single serial Modbus slave. The address of Modbus is assigned in the "Set Communication" section.

1. Operation Mode		E	Ð
Operation Mode	Normal Mode (with Translate Table)	~	

Figure 3b: "Set Communication → Operation Mode" window

- Routing Slave Address: the converter can be seen like more than one serial Modbus slave. Each serial Modbus slave is a row of the table and it is possible to assign to which TCP device is linked.
- Work with Fix IP Address: the converter can be seen like a single serial Modbus slave. The address of Modbus is assigned in the "Set Communication" section. It is not necessary to compile the Translate Table: every request that arrives on serial is transferred on TCP (using TCP format of frame) to the slave with the IP address defined in the "Set Communication" section.

MODBUS SLAVE:

This section is used to define the main parameters of Modbus line. The means of the fields are:

- In the field "Serial" the serial lien to use for Modbus communication is defined;
- In the field "Baudrate" the baudrate for the serial line is defined;
- In the field "Parity" the parity of the serial line is defined;
- In the field "Stop Bits" the number of Stop Bits is defined;
- In the field "ID Device" the address of serial Modbus device is defined. This field can be compiled only if the selected "Operation Mode" is "Normal Mode (with Translate Table)" or "Work with Fix IP Address";
- If the option "Enable Broadcast message with ID Zero" is checked, the converter will accept broadcast requests addressed to the Modbus ID 0 (only if "Routing Slave Address" mode is set);
- If the option "No Modbus Exception on TCP TimeOut" is checked, the converter does not send any exception code in case of missing response from Modbus TCP side. Otherwise, it sends the exception code 0x36.

2. Modbus Slave		Ξ
Serial	RS485	~
Baudrate	115200	~
Parity	NONE	~
Stop Bits	1	~
ID Device	1	
No Modbus Exception on T	TCP TimeOut	

Figure 3c: "Set Communication → Modbus Slave" window

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 22 of 38



MODBUS TCP MASTER:

This section is used to define the main parameters of Modbus line. The means of the fields are:

- In the field "IP Address" the IP address of the converter is defined;
- In the field "SubNet Mask" the Subnet Mask of the converter is defined;
- In the field "Gateway" the default gateway of the net is defined. This feature can be enabled or disabled pressing the Check Box field. This feature is used for going out of the net;
- In the field "Port" the TCP port for Modbus TCP communication of the converter is defined;
- If the option "Don't disconnect the socket" is checked, the converter will hold the TCP connection opened. Otherwise. It will close it after every request/response.
- In the field "Fix IP Address" the IP Address of the Modbus TCP slave is defined (only if "Work with Fix IP Address" mode is set).

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 23 of 38

3. Modbus TCP Mast	ter				Ξ
IP ADDRESS	192	. 168	. 0	. 10	
SUBNET Mask	255	. 255	. 255	. 0	
GATEWAY	192	. 168	.0	. 1	
Port	502				
TimeOut (ms)	1000				
☑ Don't disconnect the socket	t				
Fix IP Address	192	. 168	.0	. 20]

Figure 3d: "Set Communication → Modbus TCP Master" window



Document code: MN67510_ENG Revision 2.201 Page 24 of 38

NORMAL MODE (WITH TRANSLATE TABLE):

Using this function, the converter can be seen like a single serial Modbus slave. The address of Modbus is assigned in the "Set Communication" section.

By pressing the "Translate Table" button from the main window for SW67510 (Fig. 2), the window "Set Translate Table" appears (Fig. 4).

The data of the columns have the following meanings:

- In the field "Data Type" the type of Modbus data is defined;
- In the field "Address" the address of the Modbus register to which address the requests on RTU side is defined;
- ✤ In the field "IP Address TCP" the IP address of the Modbus TCP slave to which the converter will address the request is defined;
- ✤ In the field "Address TCP" the address of the Modbus register to which the converter will address the TCP request is defined;
- In the field "NPoint" the number of consecutive registers starting from the one set is defined;
- ✤ In the field "Mnemonic" a brief description is defined.

WEB T	anslate Table						—	×
Set	W6751 Translate Table	LO						
N°	Data Type	Address	IP Address TCP	Address TCP	NPoint	Mnemonic		^
1	Coil Status	100	192.168.0.18	150	5			
2	Input Status	110	192.168.0.19	100	1			
3	Holding Register	90	192.168.0.18	80	10			
4	Input Register	1	192.168.0.25	4000	100			
5								~
✓ OK ✓ Cancel Image: Cancel								

Figure 4: "Set Translate Table" window



Industrial Electronic Devices

EXAMPLE 1:

Taking the first row of Figure 4:

Step 1: A serial Modbus master do the request to the Converter to read the "Coil Status" address 100 for 5 consecutive points;

Step 2: The Converter sends to the TCP Slave 192.168.0.18 the read request of "Coil Status" address 150 for 5 consecutive points;

Step 3: The slave TCP replies to the Converter with the data;

Step 4: The Converter sends back the data on serial.

EXAMPLE 2:

Taking the second row of Figure 4:

Step 1: A serial Modbus master do the request to the Converter to read the "Input Status" address 110;

Step 2: The Converter sends to the TCP Slave 192.168.0.19 the read request of "Input Status" address 100;

Step 3: The slave TCP replies to the Converter with the data;

Step 4: The Converter sends back the data on serial.

EXAMPLE 3:

Taking the third row of Figure 4:

- Step 1: A serial Modbus master do the request to the Converter to read the "Holding Register" address 91 for 6 consecutive points;
- Step 2: The Converter sends to the TCP Slave 192.168.0.18 the read request of "Holding Register" address 81 for 6 consecutive points;
- Step 3: The slave TCP replies to the Converter with the data;
- **Step 4**: The Converter sends back the data on serial.

<u>Note:</u> If the TCP slave responds with an exception, that exception code will be transmitted to the serial master. If the TCP slave does not respond within the estimated time defined by the Timeout parameter, an exception response will be given: error code \$36.



Figure 5: Chart of Request data from serial Modbus

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 25 of 38



Document code: MN67510_ENG Revision 2.201 Page 26 of 38

ROUTING SLAVE ADDRESS:

Using this function, the converter can be seen like more than one serial Modbus slave. Each serial Modbus slave is a row of the table and it is possible to define to which TCP device is linked.

By pressing the "Translate Table" button from the main window for SW67510 (Fig. 2) the window "Set Translate Table" appears (Fig. 6).

The data of the columns have the following meanings:

- In the field "Slave ID" the ID of the virtual Modbus slave device created by the converter is defined;
- In the field "IP Address TCP" the IP address of the Modbus TCP slave device to which address the TCP requests is defined;
- ✤ In the field "Slave ID TCP" the station ID of the Modbus TCP slave device to which address the TCP requests is defined;
- If the field "Reserved Socket" is checked, the converter will reserve a socket for the specific Modbus TCP slave. This socket will be closed only after the number of consecutive errors defined in the "Errors Sock" column. It is possible to reserve up to 3 sockets for 3 different Modbus TCP slaves (function available only for Hardware Version with Dip-Switches);
- ✤ If the option "UDP" is checked, Modbus over UDP communication is enabled;
- If the option "Broadcast" is checked, the broadcast requests for that slave are accepted;
- ✤ In the field "Mnemonic" a brief description is defined.

Set	anslate Table W675 Translate Tab	1 0						- 0	×
N°	Slave ID	IP Address TCP	Slave ID TCP	Reserved Sock	Errors Sock	UDP	Broadcast	Mnemonic	^
1	1	192.168.0.18	5						
2	2	192.168.0.19	1						
3	3	192.168.0.20	4						
4	4	192.168.0.20	15						
5	5	192.168.0.15	16						~
	V OK Cancel Schere Row Iso Insert Row								

Figure 6: "Set Translate Table" *window*



Industrial Electronic Devices

EXAMPLE 1:

Taking the first row of Figure 6:

Step 1: A serial Modbus master do the request to the Converter to read/write a register from the serial slave Modbus ID 1;

Step 2: The Converter sends to the TCP slave 192.168.0.18 the read/write request using the TCP slave ID 5;

Step 3: The slave TCP replies to the Converter with the data;

Step 4: The Converter sends back the data on serial.

EXAMPLE 2:

Taking the second row of Figure 4:

Step 1: A serial Modbus master do the request to the Converter to read/write a register from the serial slave Modbus ID 2;

Step 2: The Converter sends to the TCP slave 192.168.0.19 the read/write request using the TCP slave ID 1;

Step 3: The slave TCP replies to the Converter with the data;

Step 4: The Converter sends back the data on serial.

EXAMPLE 3:

Taking the third row of Figure 4:

- Step 1: A serial Modbus master do the request to the Converter to read/write a register from the serial slave Modbus ID 4;
- Step 2: The Converter sends to the TCP slave 192.168.0.20 the read/write request using the TCP slave ID 4;
- Step 3: The slave TCP replies to the Converter with the data;
- **Step 4**: The Converter sends back the data on serial.

<u>Note:</u> If the TCP slave responds with an exception, that exception code will be transmitted to the serial master. If the TCP slave does not respond within the estimated time defined by the Timeout parameter, an exception response will be given: error code \$36.



Figure 7: Chart of Request data from serial Modbus

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 27 of 38



WORK WITH FIX IP ADDRESS:

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 28 of 38

Using this function, the converter can be seen like a single serial Modbus slave. The address of Modbus is assigned in the "Set Communication" section.

In this working mode it is not necessary to compile a Translate Table; every request that arrives on serial is transferred on TCP (using TCP format of frame) to the slave with the IP address defined in the "Set Communication" section.

EXAMPLE 1:

Using the configuration of Figure 3:

Step 1: A serial Modbus master do the request to the Converter to read/write a register from the RTU Slave Address 1;

Step 2: The Converter sends to the TCP slave 192.168.0.20 the read/write request;

Step 3: The slave TCP replies to the Converter with the data;

Step 4: The Converter sends back the data on serial.



Figure 8: Chart of Request data from serial Modbus

<u>Note:</u>

If the TCP slave responds with an exception, that exception code will be transmitted to the serial master. If the TCP slave does not respond within the estimated time defined by the Timeout parameter, an exception response will be given: error code \$36.



Document code: MN67510_ENG Revision 2.201 Page 29 of 38

UPDATE DEVICE:

By pressing the **"Update Device**" button, it is possible to load the created Configuration into the device; and also the Firmware, if necessary.

If you don't know the actual IP address of the device you have to use this procedure:

- Turn OFF the Device;
- Put Dip1 of 'Dip-Switch A' in ON position;
- Turn ON the device
- Connect the Ethernet cable;
- Insert the IP "192.168.2.205";
- Press the "Ping" button, "Device Found! must appear";
- Press the "Next" button;
- Select which operations you want to do;
- Press the "Execute update firmware" button to start the upload;
- When all the operations are "OK" turn OFF the Device;
- Put Dip1 of 'Dip-Switch A' in OFF position;
- Turn ON the device.

At this point the configuration/firmware on the device is correctly updated.

If you know the actual IP address of the device, you have to use this procedure:

- Turn on the Device with the Ethernet cable inserted;
- Insert the actual IP of the Converter;
- Press the "Ping" button, must appear "Device Found!";
- Press the "Next" button;
- Select which operations you want to do;
- Press the "Execute update firmware" button to start the upload;
- When all the operations are "OK" the device automatically goes at Normal Mode.

nto	Update Firmware from Etherner (UDP)	×
	SW67510 Update Firmware from Etherner (UDP)	
	Insert the IP Address of HD67510	
	Check the Connection the device	
	Cancel Next	
ADF	veb.com - SW67510 Ethernet Update	×
INIT :	Waiting	Ver. 1.702
FIRM	VARE : Waiting	
PROJE	ECT : Waiting	
[

Figure 9: "Update via UDP" windows



Document code: MN67510 ENG Revision 2.201 Page 30 of 38

Note:

When you install a new version of the software, if it is the first time it is better you do the update of the Firmware in the HD67510 device.



Note:

When you receive the device, for the first time, you also have to update the Firmware in the HD67510 device.

Warning:

If Fig. 10 appears when you try to do the Update try these points before seeking assistance:

- Try to repeat the operations for the updating;
- Try with another PC;
- Try to restart the PC;
- Check the LAN settings;
- Check the Wi-Fi settings;
- If you are using the program inside a Virtual Machine, try to use in the main Operating System;
- ✤ If you are using Windows Seven, Vista, 8, 10 or 11 make sure that you have the administrator privileges;
- In case you have to program more than one device, using the "UDP Update", you have to cancel the ARP table every time you connect a new device on Ethernet. For do this you have to launch the "Command Prompt" and write the command "arp -d". Pay attention that with Windows Vista, Seven, 8, 10 or 11 you have to launch the "Command Prompt" with Administrator Rights;
- ✤ Pay attention at Firewall lock.

ADFweb.com - SW67510 Ethernet Update	
INIT : Device Not Found	Ver. 1.70
FIRMWARE : Waiting	
PROJECT : Waiting	
SW67510 Ethernet Update	
INIT : PROTECTION	Ver. 1.103
FIRMWARE : PROTECTION	

Figure 10: "Error" window

In the case of HD67510 you have to use the software "SW67510": <u>www.adfweb.com\download\filefold\SW67510.zip</u>.



Document code: MN67510_ENG Revision 2.201 Page 31 of 38

MECHANICAL DIMENSIONS:





Document code: MN67510_ENG Revision 2.201 Page 32 of 38



Figure 11b: Mechanical dimensions scheme for HD67510-A1-422



Industrial Electronic Devices

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510_ENG Revision 2.201 Page 33 of 38



Figure 11c: Mechanical dimensions scheme for HD67510-B2

2D Industrial Electronic Devices

Document code: MN67510_ENG Revision 2.201 Page 34 of 38



Figure 11d: Mechanical dimensions scheme for HD67510-Slim-xxx

Industrial Electronic Devices

User Manual Modbus Slave / Modbus TCP Master

Document code: MN67510 ENG Revision 2.201 Page 35 of 38

ORDERING INFORMATIONS:

The ordering part number is formed by a valid combination of the following:

HD67510 - A 1 - xxx Modbus RTU ports None: RS232 and RS485 232: RS232 485: RS485 422: RS232 and RS422 **Connectors Type** 1: Removable 5mm Screw Terminal 2: Fixed 5mm Screw Terminal **Enclosure Type** A: 1M, 35mm DIN Rail mounting B: 4M, 35mm DIN Rail mounting Slim: 2M, 35mm DIN Rail mounting **Device Family** HD67510: Modbus Slave / Modbus TCP Master - Converter

Order Code:	HD67510-A1	- Modbus Slave / Modbus TCP Master - Converter (Housing type: A, Terminal Blocks Connectors)
Order Code:	HD67510-A1-422	- Modbus Slave / Modbus TCP Master - Converter (Housing type: A, Terminal Blocks Connectors)
Order Code:	HD67510-B2	- Modbus Slave / Modbus TCP Master - Converter (Housing type: B, Terminal Blocks Connectors)
Order Code:	HD67510-Slim-232	- Modbus Slave / Modbus TCP Master - Converter (Housing type: Slim, Terminal Blocks Connectors)
Order Code:	HD67510-Slim-485	- Modbus Slave / Modbus TCP Master - Converter (Housing type: Slim, Terminal Blocks Connectors)



Document code: MN67510_ENG Revision 2.201 Page 36 of 38

Industrial Electronic Devices

-

ACCESSORIES:

- Order Code: AC34107
- Order Code: AC34114
- Order Code: AC34011
- Order Code: AC34012
- Null Modem Cable Fem/Fem D-sub 9 Pin 5 m

Null Modem Cable Fem/Fem D-sub 9 Pin 1,5 m

- Rail DIN Power Supply 220/240V AC 50/60Hz 12 V AC
- **2** Rail DIN Power Supply 220/240V AC 50/60Hz 24 V DC



Document code: MN67510_ENG Revision 2.201 Page 37 of 38

DISCLAIMER:

All technical content within this document can be modified without notice. The content of the document is a under continual renewal. For losses due to fire, earthquake, third party access or other accidents, or intentional or accidental abuse, misuse, or use under abnormal conditions repairs are charged to the user. ADFweb.com S.r.I. will not be liable for accidental loss of use or inability to use this product, such as loss of business income. ADFweb.com S.r.I. shall not be liable for consequences of improper use.

OTHER REGULATIONS AND STANDARDS:

WEEE INFORMATION

Disposal of old electrical and electronic equipment (as in the European Union and other European countries with separate collection systems).

This symbol on the product or on its packaging indicates that this product may not be treated as household rubbish. Instead, it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. If the product is disposed correctly, you will help prevent potential negative environmental factors and impact of human health, which could otherwise be caused by inappropriate disposal. The recycling of materials will help to conserve natural resources. For more information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

RESTRICTION OF HAZARDOUS SUBSTANCES DIRECTIVE

The device respects the 2002/95/EC Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment (commonly referred to as Restriction of Hazardous Substances Directive or RoHS).

CE MARKING

C The product conforms with the essential requirements of the applicable EC directives.



Document code: MN67510_ENG Revision 2.201 Page 38 of 38

WARRANTIES AND TECHNICAL SUPPORT:

For fast and easy technical support for your ADFweb.com SRL products, consult our internet support at <u>www.adfweb.com</u>. Otherwise contact us at the address support@adfweb.com

RETURN POLICY:

If while using your product you have any problem and you wish to exchange or repair it, please do the following:

- Obtain a Product Return Number (PRN) from our internet support at <u>www.adfweb.com</u>. Together with the request, you need to provide detailed information about the problem.
- Send the product to the address provided with the PRN, having prepaid the shipping costs (shipment costs billed to us will not be accepted).

If the product is within the warranty of twelve months, it will be repaired or exchanged and returned within three weeks. If the product is no longer under warranty, you will receive a repair estimate.



ADFweb.com S.r.I. Via Strada Nuova, 17 IT-31010 Mareno di Piave TREVISO (Italy) Phone +39.0438.30.91.31 Fax +39.0438.49.20.99 www.adfweb.com

