

User Manual

Revision 1.200

English

BACnet Master / Modbus Slave - Converter

(Order Code: HD67712-IP-2-A1 , HD67712-IP-4-A1,
HD67712-MSTP-2-A1, HD67712-MSTP-4-A1)

For Website information:

www.adfweb.com?Product=HD67712

For Price information:

www.adfweb.com?Price=HD67712-IP-2-A1

www.adfweb.com?Price=HD67712-IP-4-A1

www.adfweb.com?Price=HD67712-MSTP-2-A1

www.adfweb.com?Price=HD67712-MSTP-4-A1

Benefits and Main Features:

- ✚ Triple Electrical isolation
- ✚ Temperature range: -40°C/+85°C (-40°F/+185°F)

For other BACnet products see also the following link:

Converter BACnet Master to

www.adfweb.com?Product=HD67704
www.adfweb.com?Product=HD67714
www.adfweb.com?Product=HD67716
www.adfweb.com?Product=HD67717
www.adfweb.com?Product=HD67718
www.adfweb.com?Product=HD67719
www.adfweb.com?Product=HD67721
www.adfweb.com?Product=HD67722
www.adfweb.com?Product=HD67723
www.adfweb.com?Product=HD67725
www.adfweb.com?Product=HD67726
www.adfweb.com?Product=HD67737
www.adfweb.com?Product=HD67801
www.adfweb.com?Product=HD67832
www.adfweb.com?Product=HD67937
www.adfweb.com?Product=HD67965
www.adfweb.com?Product=HD67B31
www.adfweb.com?Product=HD67D16
www.adfweb.com?Product=HD67E05
www.adfweb.com?Product=HD67E55
www.adfweb.com?Product=HD67F16

(DMX)
 (Modbus TCP Slave)
 (PROFIBUS Slave)
 (CAN)
 (CANopen)
 (PROFINET Slave)
 (DeviceNet Slave)
 (EtherNet/IP Slave)
 (NMEA 2000)
 (J1939)
 (SNMP Agent)
 (IEC 61850 Server)
 (KNX)
 (DALI)
 (MQTT)
 (IO-Link Slave)
 (OPC UA Server)
 (LoRaWAN)
 (EtherCAT Slave)
 (EtherCAT Master)
 (LoRaWAN Gateway)

Do you have your customer protocol? Then go to:

www.adfweb.com?Product=HD67003

Do you need to choose a device? Do you want help?

www.adfweb.com?Cmd=helpme



User Manual

INDEX:

	Page
INDEX	2
UPDATED DOCUMENTATION	2
REVISION LIST	2
WARNING	2
TRADEMARKS	2
SECURITY ALERT	3
EXAMPLE OF CONNECTION	4
CONNECTION SCHEME	6
CHARACTERISTICS	10
CONFIGURATION	10
POWER SUPPLY	11
FUNCTION MODES	12
LEDS (for HD67712-IP-x-A1)	13
LEDS (for HD67712-MSTP-2-A1)	14
LEDS (for HD67712-MSTP-4-A1)	15
RS485 (for HD67712-IP-4-A1, HD67712-MSTP-2/4-A1)	16
RS232 (for HD67712-IP-4-A1, HD67712-MSTP-2-A1)	17
ETHERNET	18
USE OF COMPOSITOR SW67712	19
NEW CONFIGURATION / OPEN CONFIGURATION	20
SOFTWARE OPTIONS	21
SET COMMUNICATION	23
SET BACNET ACCESS	25
UPDATE DEVICE	29
MECHANICAL DIMENSIONS	31
ORDERING INFORMATIONS	35
ACCESSORIES	35
DISCLAIMER	36
OTHER REGULATIONS AND STANDARDS	36
WARRANTIES AND TECHNICAL SUPPORT	37
RETURN POLICY	37

UPDATED DOCUMENTATION:

Dear customer, we thank you for your attention and we remind you that you need to check that the following document is:

- ✚ Updated
- ✚ Related to the product you own

To obtain the most recently updated document, note the “document code” that appears at the top right-hand corner of each page of this document.

With this “Document Code” go to web page www.adfweb.com/download/ and search for the corresponding code on the page. Click on the proper “Document Code” and download the updates.

REVISION LIST:

Revision	Date	Author	Chapter	Description
1.000	20/12/2013	Fl	All	First Release
1.100	03/06/2014	Ff	All	Add MSTP and PTP versions
1.110	10/03/2016	Fl	All	Software changed (v1.100)
1.200	19/06/2024	Ln	All	Revision

WARNING:

ADFweb.com reserves the right to change information in this manual about our product without warning.

ADFweb.com is not responsible for any error this manual may contain.

TRADEMARKS:

All trademarks mentioned in this document belong to their respective owners.

SECURITY ALERT:**GENERAL INFORMATION**

To ensure safe operation, the device must be operated according to the instructions in the manual. When using the device, legal and safety regulation are required for each individual application. The same applies also when using accessories.

INTENDED USE

Machines and systems must be designed so the faulty conditions do not lead to a dangerous situation for the operator (i.e. independent limit switches, mechanical interlocks, etc.).

QUALIFIED PERSONNEL

The device can be used only by qualified personnel, strictly in accordance with the specifications. Qualified personnel are persons who are familiar with the installation, assembly, commissioning and operation of this equipment and who have appropriate qualifications for their job.

RESIDUAL RISKS

The device is state-of-the-art and is safe. The instruments can represent a potential hazard if they are inappropriately installed and operated by untrained personnel. These instructions refer to residual risks with the following symbol:






This symbol indicates that non-observance of the safety instructions is a danger for people that could lead to serious injury or death and / or the possibility of damage.

CE CONFORMITY

The declaration is made by our company. You can send an email to support@adfweb.com or give us a call if you need it.

EXAMPLES OF CONNECTION:





CONNECTION SCHEME:

Dip-Switch A:



-Dip1 – Functioning Mode



= Normal



= Boot



Rail DIN
Clamp

Led1:
Green
ON

Led2:
Green
Modbus comm.

Led3:
Green
Device state

Led4:
Green
Not used

Led5:
Green
Ethernet1 Tx

Connector3:
Ethernet1 Port
(RJ45 Plug)

Led6:
Green
Ethernet2 Tx

Connector4:
Ethernet2 Port
(RJ45 Plug)

Tx Rx GND +V 0V

Connector2:

RS232 (Isolated port)
GND = Ground* (to Isolated Ground)
Rx = Rx line
Tx = Tx line

Connector1:

Power Supply port

0V = Ground

+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V

Figure 1a: Connection scheme for HD67712-IP-2-A1







Figure 1b: Connection scheme for HD67712-IP-4-A1

Dip-Switch A:

-Dip1 – Functioning Mode

 = Normal  = Boot



Dip-Switch B:

-Dip1 – RS485 Termination Resistor

 = Open  = 220 Ohm

-Dip2 – Not used

Connector3:

RS485 (Isolated port)

S = Shield* (to Isolated Ground)
B = Negative wire
A = Positive wire

Connector1:

Power Supply port

0V = Ground
+V = Positive wire

V AC: min 8V ; max 24V
V DC: min 12V ; max 35V

Led4:
Green
Modbus comm.

Led3:
Green
BACnet comm.

Led2:
Green
Ethernet Link

Connector5:
Ethernet Port
(RJ45 Plug)

Led1:
Green
Device State

Connector 4:

Port RS232 (D-SUB9-Male)
(Isolated Port)

PIN2 = RX
PIN3 = TX
PIN5 = GND* (to Isolated Ground)

Used for:
- Programming Port
- Modbus on RS232

To connect the device to the COM port of a PC in order to set it you have to use the programming cable AC34107 or a cable made as showed here:




Figure 1c: Connection scheme for HD67712-MSTP-2-A1




Figure 1d: Connection scheme for HD67712-MSTP-4-A1

CHARACTERISTICS:

The HD67712-IP-x-A1 and HD67712-MSTP-x-A1 are BACnet Master / Modbus Slave Converters.

It allows for the following characteristics:

- Up to 512 BACnet objects in reading and 512 objects in writing;
- Triple isolation between RS232/485 - Power Supply, RS232/RS485 - Ethernet, Ethernet - Power Supply;
- Two-directional information between Modbus bus and BACnet bus;
- Mountable on 35mm Rail DIN;
- Wide power supply input range: 8...24V AC or 12...35V DC;
- Wide temperature range: -40°C / +85°C [-40°F / +185°F].


CONFIGURATION:

You need Compositor SW67712 software on your PC in order to perform the following:

- Define the parameters of BACnet line;
- Define the parameters of Modbus line;
- Define the BACnet objects that a Modbus Master can read;
- Define the BACnet objects that a Modbus Master can write;
- Update the device.

POWER SUPPLY:

The devices can be powered at 8...24V AC and 12...35V DC. For more details see the two tables below.

VAC 		VDC 	
Vmin	Vmax	Vmin	Vmax
8V	24V	12V	35V

Consumption at 24V DC:

Device	Consumption [W/VA]
HD67712-IP-x-A1	3.5
HD67712-MSTP-x-A1	3.5

Connector1:


Power Supply port

0V = Ground

+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V



Connector1:


Power Supply port

0V = Ground


+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V



Caution: Do not reverse the polarity power



HD67712-IP-2-A1
HD67712-IP-4-A1
HD67712-MSTP-2-A1
HD67712-MSTP-4-A1


FUNCTION MODES:

The device has got two functions mode depending of the position of the Dip1 of 'Dip-Switch A':

- The first, with Dip1 in Off position (factory setting), is used for the normal working of the device.
- The second, with Dip1 in On position, is used for upload the Project/Firmware.

For the operations to follow for the updating (see 'UPDATE DEVICE' section).


According to the functioning mode, the LEDs will have specifics functions (see 'LEDS' section).



LEDS (for HD67712-IP-x-A1):

The device has got six LEDs that are used to give information about the functioning status.
The various meanings of the LEDs are described in the table below.


LED	Normal Mode	Boot Mode
1: ON [supply voltage] (green)	ON: Device powered OFF: Device not powered	ON: Device powered OFF: Device not powered
2: Modbus comm. (green)	Change state when arrive Modbus requests	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
3: Device state (green)	Blinks slowly (~1Hz)	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
4: Not used (green)	OFF	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
5: Ethernet1 Tx (green)	Blinks when is transmitting Ethernet frames	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
6: Ethernet2 Tx (green)	Blinks when is transmitting Ethernet frames	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress



LEDS (for HD67712-MSTP-2-A1):

The device has got four LEDs that are used to give information about the functioning status.
The various meanings of the LEDs are described in the table below.


LED	Normal Mode	Boot Mode
1: Device State (green)	Blinks slowly ($\sim 1\text{Hz}$)	ON: Device powered OFF: Device not powered
2: Ethernet Link (green)	ON: Ethernet cable connected OFF: Ethernet cable disconnected	Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress
3: BACnet comm. (green)	Blinks when BACnet data (RS232/RS485) are received	Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress
4: Modbus comm. (green)	Blinks when Modbus data (RS232/RS485) are received	Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress



LEDS (for HD67712-MSTP-4-A1):


The device has got four LEDs that are used to give information about the functioning status.
The various meanings of the LEDs are described in the table below.

LED	Normal Mode	Boot Mode
1: Device State (green)	Blinks slowly ($\sim 1\text{Hz}$)	ON: Device powered OFF: Device not powered
2: Ethernet Link (green)	ON: Ethernet cable connected OFF: Ethernet cable disconnected	Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress
3: BACnet comm. (green)	Blinks when BACnet data (RS232/RS485) are received	Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress
4: Modbus comm. (green)	Blinks when Modbus data (RS232/RS485) are received	Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress



RS485 (for HD67712-IP-4-A1 and HD67712-MSTP-2/4-A1):

To terminate the RS485 line with a 220Ω resistor it is necessary to put ON dip 1, like in figure.



The maximum length of the cable should be 1200m (4000 feet).



Here some codes of cables:

- Belden: p/n 8132 - 2x 28AWG stranded twisted pairs conductor + foil shield + braid shield;
- Belden p/n 82842 - 2x 24AWG stranded twisted pairs conductor + foil shield + braid shield;
- Tasker: p/n C521 - 1x 24AWG twisted pair conductor + foil shield + braid shield;
- Tasker: p/n C522 - 2x 24AWG twisted pairs conductor + foil shield + braid shield.

RS232 (for HD67712-IP-4-A1 and HD67712-MSTP-2-A1):


The connection from a RS232 socket to a serial port (example one from a personal computer) must be made with a NULL MODEM cable (a serial cable where the pins 2 and 3 are crossed).

It is recommended that the RS232 cable not exceed 15 meters.



ETHERNET:

The BACnet/IP connection and the updating of the converters must be made using Connector3 and/or Connector4 and/or Connector5 of HD67712 with at least a Category 5E cable. The maximum length of the cable should not exceed 100m. The cable has to conform to the T568 norms relative to connections in cat.5 up to 100 Mbps. To connect the device to an Hub/Switch is recommended the use of a straight cable, to connect the device to a PC/PLC/other is recommended the use of a cross cable.



USE OF COMPOSITOR SW67712:

To configure the Converter, use the available software that runs with Windows called SW67712. It is downloadable on the site www.adfweb.com and its operation is described in this document. *(This manual is referenced to the last version of the software present on our web site)*. The software works with MSWindows (XP, Vista, Seven, 8, 10 or 11; 32/64bit).

When launching the SW67712, the window below appears (Fig. 2).

**Note:**

It is necessary to have installed .Net Framework 4.



Figure 2: Main window for SW67712


NEW CONFIGURATION / OPEN CONFIGURATION:

The “**New Configuration**” button creates the folder which contains the entire device’s configuration.




A device’s configuration can also be imported or exported:


- To clone the configurations of a programmable “BACnet Master / Modbus Slave - Converter” in order to configure another device in the same manner, it is necessary to maintain the folder and all its contents;
- To clone a project in order to obtain a different version of the project, it is sufficient to duplicate the project folder with another name and open the new folder with the button “**Open Configuration**”.




SOFTWARE OPTIONS:

By pressing the “**Settings**” () button there is the possibility to change the language of the software and check the updatings for the compositor.

In the section “Language” it is possible to change the language of the software.



In the section “Connection Options”, it is possible to check if there are some updatings of the software compositor in ADFweb.com website. Checking the option “**Check Software Update at Start of Program**”, the SW67712 check automatically if there are updatings when it is launched.



In the section "Software Settings", it is possible to enable/disable some keyboard's commands for an easier navigation inside the tables contained in the different sections of the software.

SET COMMUNICATION:

This section define the fundamental communication parameters of two buses, BACnet and Modbus.

By Pressing the **"Set Communication"** button from the main window for SW67712 (Fig. 2) the window "Set Communication" appears (Fig. 3).

In the section "BACnet Type" is possible to select the type of BACnet to use from:

- BACnet/IP (uses ethernet);
- BACnet MS/TP (uses RS485);

If selected "BACnet/IP" the means of the fields for "BACnet" are:

- In the fields **"IP ADDRESS"** insert the IP address that you want to give to the Converter;
- In the fields **"SUBNET Mask"** insert the SubNet Mask;
- In the fields **"GATEWAY"** insert the default gateway that you want to use. This feature can be enabled or disabled pressing the Check Box field. This feature is used for going out of the net;
- In the field **"Port"** the port number used for BACnet communication is defined. The default port used for BACnet communication is 47808, but is possible to insert any value (except 10000 and 10001);
- In the field **"BACnet Device Name"** is possible to assign a name to the BACnet node;
- In the field **"Device Instance"** is possible to assign a number to the BACnet node;
- In the field **"TimeOut Polling (ms)"** the timeout for the BACnet requests is defined.

The means of the fields for the "Modbus Slave" section are the same for all types of BACnet:

- In the field **"Serial"** the serial lien to use for Modbus communication is defined (RS232 or RS485);
- In the field **"Baudrate"** the baudrate for the serial line is defined;
- In the field **"Parity"** the parity of the serial line is defined;
- In the field **"Stop Bits"** the number of Stop Bits is defined;
- In the **"ID Device"** field the Modbus Slave ID is defined.




Figure 3a: "Set Communication → BACnet/IP window"

If selected "BACnet MS/TP" the means of the fields for "BACnet" are:

- In the field "**Baudrate**" it is possible to select the baudrate of the BACnet line;
- In the field "**Parity**" it is possible to select the parity of the line;
- In the field "**BACnet Device Name**" is possible to insert the name to give to the BACnet node (maximum 17 characters);
- In the field "**MAC Address**" is possible to define the MAC of BACnet node (from 0 to 254);
- The field "**Max Masters**" specifies the highest allowable address for master nodes. The value shall be less than or equal to 127;
- The field "**Max Info Frames**" specifies the maximum number of information frames the node may send before it must pass the token;
- In the field "**Device Instance**" is possible to assign a number to the BACnet node.





Figure 3b: "Set Communication → BACnet/MSTP" window

SET BACNET ACCESS:

By Pressing the "**Set BACnet Access**" button from the main window of SW67712 (Fig. 2), the window "Set Communication" appears (Fig. 4).

The window is divided in two parts, the "**BACnet in Read**" that contains the BACnet objects that the Converter goes to read from the slaves; and "**BACnet in Write**" that contains the BACnet objects that the Converter goes to write into the slaves.




N	Enable	Slave ID	Object Type	Instance	Property	NByte	En Dest	D Net	D Len	D Add	Poll Time	Max Err	Position	Start Bit	Swap	Float To Int	Molt. Factor	Mnemonic
1	<input checked="" type="checkbox"/>	192.168.2.33	Analog Input	0	Present Value (85)	4	<input type="checkbox"/>				1000	0	0	0	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
2	<input checked="" type="checkbox"/>						<input type="checkbox"/>								<input type="checkbox"/>	<input type="checkbox"/>		
3	<input checked="" type="checkbox"/>						<input type="checkbox"/>								<input type="checkbox"/>	<input type="checkbox"/>		
4	<input checked="" type="checkbox"/>						<input type="checkbox"/>								<input type="checkbox"/>	<input type="checkbox"/>		
5	<input checked="" type="checkbox"/>						<input type="checkbox"/>								<input type="checkbox"/>	<input type="checkbox"/>		
6	<input checked="" type="checkbox"/>						<input type="checkbox"/>								<input type="checkbox"/>	<input type="checkbox"/>		

Figure 4a: "BACnet Set Access → BACnet Read" window

The means of the fields in the window (Read) are the follows:

- If the field "**Enable**" is checked, the BACnet variable is enabled;
- In the field "**Slave ID**" insert the IP address or ID of the slave that contains the data to be read;
- In the field "**Object Type**" select the object to be read;
- In the field "**Instance**", define the instance number of the object;
- In the field "**Property**" select the property to be read;
- In the field "**NByte**", define the number of bytes reserved for saving the information on Modbus;
- By checking the field "**En Dest**" is possible to enable the Destination Network (D Net), Destination Length (D Len) and Destination Address (D Adr). These informations are used for make a request to other segments of network;
- In the field "**D Net**" define the destination network (from 1 to 65535);

- In the field "**D Len**" define the length of "D Add" field (1 or 2 or 6);
- In the field "**D Add**" define the address of the endpoint. If "D Len" is one is possible to insert a number from 1 to 255; if "D Len" is two is possible to insert a number from 1 to 65535; if "D Len" is 6 is possible to insert an IP and port in this format "192.168.2.188:47808";
- In the field "**Poll Time**" define the frequency of the request;
- In the field "**Max Error**" insert the number of consecutive errors that the Master waits before discard the row from the cycle of requests;
- In the field "**Position**" is possible to select the position where save the data into a 1440 bytes array (readable by Modbus);
- The field "**Start Bit**" is used for the "Binary Input" and "Binary Output" BACnet objects. Is possible to select the position in the byte where save the data;
- By checking the field "**Swap**" it is possible to swap the order of data readed from BACnet slave;
- By checking the field "**Float To Int**" it is possible to convert the format from Float to Int;
- In the field "**Molt. Factor**" it is possible to define a factor for the converted data;
- In the field "**Mnemonic**" is possible to insert a description of the data inserted in the row.



N	Enable	Slave ID	Object Type	Data Type	Instance	Property	Priority	NByte	En Dest	D Net	D Len	D Add	Change	OnCMD	Timer	Poll Time	Max Err	Position	Start Bit	Swap	Int To Float	Molt. Factor	Mnemonic
1	<input checked="" type="checkbox"/>	192.168.2.202	Analog Value	Real	0	Present Value (85)	0	4	<input checked="" type="checkbox"/>	2	1	13	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1000	0	0	0	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
2	<input checked="" type="checkbox"/>								<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>	<input type="checkbox"/>		
3	<input checked="" type="checkbox"/>								<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>	<input type="checkbox"/>		
4	<input checked="" type="checkbox"/>								<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>	<input type="checkbox"/>		
5	<input checked="" type="checkbox"/>								<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>	<input type="checkbox"/>		
6	<input checked="" type="checkbox"/>								<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>	<input type="checkbox"/>		
7	<input checked="" type="checkbox"/>								<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>	<input type="checkbox"/>		

Figure 4b: "BACnet Set Access → BACnet Write" window

The means of the fields in the window (Write) are the follows:

- If the field "**Enable**" is checked, the BACnet variable is enabled;
- In the field "**Slave ID**" insert the IP address or ID of the slave where the data are written;
- In the field "**Object Type**" select the object to be written;
- In the field "**Data Type**" the type of data to write is defined;
- In the field "**Instance**", define the instance number of the object;
- In the field "**Property**" select the property to be written;
- In the field "**Priority**" define the priority of the frame (from 0 to 16). If is 0, means the frame doesn't contain the Priority tag.
- In the field "**NByte**", define the number of bytes sent in the request;
- By checking the field "**En Dest**" is possible to enable the Destination Network (D Net), Destination Length (D Len) and Destination Address (D Adr). These informations are used for make a request to other segments of network;
- In the field "**D Net**" define the destination network (from 1 to 65535);
- In the field "**D Len**" define the length of "D Add" field (1 or 2 or 6);
- In the field "**D Add**" define the address of the endpoint. If "D Len" is one is possible to insert a number from 1 to 255; if "D Len" is two is possible to insert a number from 1 to 65535; if "D Len" is 6 is possible to insert an IP and port in this format "192.168.2.188:47808";

- By checking the field "**Change**" the BACnet write request is made only if Modbus data are changed; otherwise (if is selected the field "**Timer**") is sent cyclically, using the "Poll Time";
- By checking the field "**OnCMD**" the BACnet write request is sent at the reception of a Modbus request;
- In the field "**Poll Time**" define the frequency of the request;
- In the field "**Max Error**" insert the number of consecutive errors that the Master waits before discard the row from the cycle of requests;
- In the field "**Position**" is possible to select the position where take the data to write in the request from a 1440 bytes array (writeable by Modbus);
- The field "**Start Bit**" is used for the "Binary Output" BACnet objects. Is possible to select the position in the byte where save the data;
- By checking the field "**Swap**" is possible to swap the order of data written to the BACnet slave;
- By checking the field "**Float To Int**" it is possible to convert the format from Int to Float;
- In the field "**Molt. Factor**" it is possible to define a factor for the converted data;
- In the field "**Mnemonic**" is possible to insert a description of the data inserted in the row.

UPDATE DEVICE:

By pressing the **"Update Device"** button, it is possible to load the created Configuration into the device; and also the Firmware, if necessary. This by using the Ethernet port.

If you don't know the actual IP address of the device you have to use this procedure:

- Turn OFF the Device;
- Put Dip1 of 'Dip-Switch A' in ON position;
- Turn ON the device
- Connect the Ethernet cable;
- Insert the IP **"192.168.2.205"**;
- Select which operations you want to do;
- Press the **"Execute update firmware"** button to start the upload;
- When all the operations are "OK" turn OFF the Device;
- Put Dip1 of 'Dip-Switch A' in OFF position;
- Turn ON the device.

If you know the actual IP address of the device, you have to use this procedure:

- Turn ON the Device with the Ethernet cable inserted;
- Insert the actual IP of the Converter;
- Select which operations you want to do;
- Press the **"Execute update firmware"** button to start the upload;
- When all the operations are "OK" the device automatically goes at Normal Mode.

At this point the configuration/firmware on the device is correctly updated.



Figure 5: "Update device" windows

**Note:**

When you receive the device, for the first time, you also have to update the Firmware in the HD67712 device.

**Warning:**

If Fig. 6 appears when you try to do the Update try these points before seeking assistance:

- Try to repeat the operations for the updating;
- Try with another PC;
- Try to restart the PC;
- Check the LAN settings;
- If you are using the program inside a Virtual Machine, try to use in the main Operating System;
- If you are using Windows Seven, Vista, 8, 10 or 11 make sure that you have the administrator privileges;
- In case you have to program more than one device, using the "UDP Update", you have to cancel the ARP table every time you connect a new device on Ethernet. For do this you have to launch the "Command Prompt" and write the command "arp -d". Pay attention that with Windows Vista, Seven, 8, 10 or 11 you have to launch the "Command Prompt" with Administrator Rights;
- Pay attention at Firewall lock.





Figure 6: "Error" window

**Warning:**

In the case of HD67712 you have to use the software "HD67712": www.adfweb.com/download/filefold/SW67712.zip.

MECHANICAL DIMENSIONS:



Housing: PVC
Weight: 200g (Approx)

Figure 7a: Mechanical dimensions scheme for HD67712-IP-2-A1





Figure 7b: Mechanical dimensions scheme for HD67712-IP-4-A1



Housing: PVC
Weight: 200g (Approx)

Figure 7c: Mechanical dimensions scheme for HD67712-MSTP-2-A1





Figure 7d: Mechanical dimensions scheme for HD67712-MSTP-4-A1

ORDERING INFORMATION:

The ordering part number is formed by a valid combination of the following:

HD67712 - xxx - x - A1



Connectors Type

- 1: Removable 5mm Screw Terminal
- 2: Fixed 5mm Screw Terminal

Enclosure Type

- A: 1M, 35mm DIN Rail mounting
- B: 4M, 35mm DIN Rail mounting

Modbus port

- 2: RS232
- 4: RS485

BACnet type

- IP: BACnet/IP
- MSTP: BACnet MSTP

Device Family

- HD67712: BACnet Master / Modbus Slave - Converter

- | | | |
|--------------------------------------|---|---|
| Order Code: HD67712-IP-2-A1 | - | BACnet/IP Master / Modbus Slave - Converter (Modbus on RS232) |
| Order Code: HD67712-IP-4-A1 | - | BACnet/IP Master / Modbus Slave - Converter (Modbus on RS485) |
| Order Code: HD67712-MSTP-2-A1 | - | BACnet MSTP Master / Modbus Slave - Converter (Modbus on RS232) |
| Order Code: HD67712-MSTP-4-A1 | - | BACnet MSTP Master / Modbus Slave - Converter (Modbus on RS485) |

ACCESSORIES:

- | | | |
|----------------------------|---|--|
| Order Code: AC34011 | - | 35mm Rail DIN - Power Supply 220/240V AC 50/60Hz - 12 V DC |
| Order Code: AC34012 | - | 35mm Rail DIN - Power Supply 220/240V AC 50/60Hz - 24 V DC |

DISCLAIMER:

All technical content within this document can be modified without notice. The content of the document is a under continual renewal. For losses due to fire, earthquake, third party access or other accidents, or intentional or accidental abuse, misuse, or use under abnormal conditions repairs are charged to the user. ADFweb.com S.r.l. will not be liable for accidental loss of use or inability to use this product, such as loss of business income. ADFweb.com S.r.l. shall not be liable for consequences of improper use.

OTHER REGULATIONS AND STANDARDS:**WEEE INFORMATION**

Disposal of old electrical and electronic equipment (as in the European Union and other European countries with separate collection systems).

— This symbol on the product or on its packaging indicates that this product may not be treated as household rubbish. Instead, it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. If the product is disposed correctly, you will help prevent potential negative environmental factors and impact of human health, which could otherwise be caused by inappropriate disposal. The recycling of materials will help to conserve natural resources. For more information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

RESTRICTION OF HAZARDOUS SUBSTANCES DIRECTIVE

The device respects the 2002/95/EC Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment (commonly referred to as Restriction of Hazardous Substances Directive or RoHS).

CE MARKING

The product conforms with the essential requirements of the applicable EC directives.

WARRANTIES AND TECHNICAL SUPPORT:

For fast and easy technical support for your ADFweb.com SRL products, consult our internet support at www.adfweb.com. Otherwise contact us at the address support@adfweb.com

RETURN POLICY:

If while using your product you have any problem and you wish to exchange or repair it, please do the following:

- Obtain a Product Return Number (PRN) from our internet support at www.adfweb.com. Together with the request, you need to provide detailed information about the problem.
- Send the product to the address provided with the PRN, having prepaid the shipping costs (shipment costs billed to us will not be accepted).

If the product is within the warranty of twelve months, it will be repaired or exchanged and returned within three weeks. If the product is no longer under warranty, you will receive a repair estimate.



ADFweb.com S.r.l.
Via Strada Nuova, 17
IT-31010 Mareno di Piave
TREVISO (Italy)
Phone +39.0438.30.91.31
Fax +39.0438.49.20.99
www.adfweb.com

