



QR of Manual

[www.adfweb.com/download/
filefold/MN67597_ENG.pdf](http://www.adfweb.com/download/filefold/MN67597_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67597-A1_ENG.pdf](http://www.adfweb.com/download/filefold/BS67597-A1_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67597.zip](http://www.adfweb.com/download/filefold/SW67597.zip)

HD67597-A1

BOX SHEET

EtherNet/IP / DeviceNet Master - Converter

Box Sheet for Order code: HD67597-A1
Document code: BS67597-A1
V1.002



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67597-A1

Dip-Switch A:


-Dip1 – Functioning Mode



= Normal



= Boot



Led1:

Green
ON

Led2:

Green
DeviceNet comm.

Led3:

Green
Device State

Led4:

Green
Not used

Led5:

Green
Ethernet1 Link

Connector3:

Ethernet1 Port
(RJ45 Plug)

Led6:

Green
Ethernet2 Link

Connector4:

Ethernet2 Port
(RJ45 Plug)

Dip-Switch B:

-Dip1 – CAN Termination Resistor



= Open



= 120 Ohm

Connector2:

CANopen port (Isolated port)

Hi = High wire

Shl = Shield* (to Isolated Ground)

Lo = Low wire

Connector1:

Power Supply port

0V = Ground

+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V

Order code: HD67597-A1