

EXTERNAL LINKS

HD67622-485-A1



QR of Manual

[www.adfweb.com/download/
filefold/MN67622_ENG.pdf](http://www.adfweb.com/download/filefold/MN67622_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67622-485-A1_ENG.pdf](http://www.adfweb.com/download/filefold/BS67622-485-A1_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67622.zip](http://www.adfweb.com/download/filefold/SW67622.zip)

HD67622-485-A1

BOX SHEET

S7comm / Modbus Slave Converter

Box Sheet for Order code: HD67622-485-A1
Document code: BS67622-485-A1
V1.000



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com


CONNECTION SCHEME

Order code: HD67622-485-A1

Dip-Switch A:

-Dip1 – Functioning Mode

 = Normal  = Boot



Rail DIN
Clamp

Led1:
Green
ON

Led2:
Green
Device state

Led3:
Green
Modbus comm.

Led4:
Green
S7comm comm.

Led5:
Green
Ethernet1 Tx

Connector3:
Ethernet1 port
(RJ45 Plug)

Led6:
Green
Ethernet2 Tx

Connector4:
Ethernet2 port
(RJ45 Plug)

Connector1:
Power Supply port
0V = Ground
+V = Positive wire
V AC: min 8V ; max 24V
V DC: min 12V ; max 35V

Dip-Switch B:

-Dip1 – RS485 Termination Resistor


 = Open  = 120 Ohm

-Dip2 – Not used

Connector2:

RS485 (Isolated port)

S = Shield* (to Isolated Ground)
B = Negative wire
A = Positive wire



Order code: HD67622-485-A1