



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67974ENG.pdf](http://www.adfweb.com/download/filefold/MN67974ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67974-B2-IB\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67974-B2-IB_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67974.zip](http://www.adfweb.com/download/filefold/SW67974.zip)

**HD67974-B2-IB**

# BOX SHEET

**IO-Link Slave / EtherNet/IP slave  
Converter**

Box Sheet for Order code: HD67974-B2-IB  
Document code: BS67974-B2-IB  
V1.000



**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67974-B2-IB

## Connector4:

Power supply for actuators UA (24 V DC)

+ = + 24 V DC

0V = Ground reference

## Connector1:

Power Supply port

1 = Supply for converter US, +24 V

2 = Supply for actuators UA, +24 V

3 = Ground reference US, 0 V

4 = C/Q, IO-Link channel

5 = Ground reference UA, 0 V



## Led3:


Green  
Ethernet/IP comm.

## Led4:

Error state

## Connector3:

Ethernet Port  
(RJ45 Plug)



## Led5:

Green  
UA supply active

## Led1:

Green  
Device state

## Dip-Switch A:

-Dip1 – Functioning Mode

Normal = = boot =

## Led2:

Green  
IO-Link comm.

Order code: HD67974-B2-IB