



QR of Manual

[www.adfweb.com/download/
filefold/MN67B11_ENG.pdf](http://www.adfweb.com/download/filefold/MN67B11_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67B11-IP-B2_ENG.pdf](http://www.adfweb.com/download/filefold/BS67B11-IP-B2_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67B11.zip](http://www.adfweb.com/download/filefold/SW67B11.zip)

HD67B11-IP-B2

BOX SHEET

OPC UA Client / BACnet/IP Slave - Converter

Box Sheet for order code: HD67B11-IP-B2
Document code: BS67B11-IP-B2
V1.001



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67B11-IP-B2


Dip-Switch A: -Dip1 - Functioning Mode



= Normal Mode



= Boot Mode




Led1:
Green
Device state

Led2:
Yellow
OPC UA comm.

Led3:
Yellow
BACnet comm.

Led4:
Yellow
Error state



Connector3:
Ethernet Port
(RJ45 Plug)

Led5:
Green
Link Ethernet



Connector1:
Power Supply

0V = Ground
+V = Positive wire

V AC: min 8V ; max 24V
V DC: min 12V ; max 35V

Order code: HD67B11-IP-B2