



QR of Manual

[www.adfweb.com/download/
filefold/MN67B80-B2_ENG.pdf](http://www.adfweb.com/download/filefold/MN67B80-B2_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67B80-B2_ENG.pdf](http://www.adfweb.com/download/filefold/BS67B80-B2_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67B80.zip](http://www.adfweb.com/download/filefold/SW67B80.zip)

HD67B80-B2

BOX SHEET

PROFINET Master / MQTT - Converter

Box Sheet for Order code: HD67B80-B2
Document code: BS67B80-B2
V1.000



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com


CONNECTION SCHEME

Order code: HD67B80-B2

Dip-Switch B: -Dip1 – Functioning Mode

 = Normal Mode

 = Boot Mode




Led1:
Green
Device state

Led2:
Yellow
MQTT comm.

Led3:
Yellow
PROFINET comm.

Led4:
Yellow
Comm. error



Connector3:
Ethernet Port
(RJ45 Plug)

Led5:
Green
Link Ethernet



Connector1:
Power Supply
0V = Ground
+V = Positive wire
V AC: min 8V ; max 24V
V DC: min 12V ; max 35V