

EXTERNAL LINKS

HD67020-B2-xx



QR of Manual

[www.adfweb.com/download/
filefold/MN67020-B2_ENG.pdf](http://www.adfweb.com/download/filefold/MN67020-B2_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67020-B2_ENG.pdf](http://www.adfweb.com/download/filefold/BS67020-B2_ENG.pdf)

BOX SHEET

**M-Bus Master / RS232 - Converter
(up to xx Slaves)**

Box Sheet for Order code: HD67020-B2-xx
Document code: BS67020-B2
V1.030



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

HD67020-B2-xx

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67020-B2-xx



Connector3:

RS232 (Isolated Port)

Tx = Device Tx


Rx = Device Rx

Shl = Shield (to Isolated Ground)

Led1:

Green

Device State



Connector2:

Power Supply

0V = Ground

+V = Positive wire

V AC: min 15V ; max 21V

V DC: min 18V ; max 35V

Connector1:

M-Bus

(unpolarized)

Order code: HD67020-B2-xx