



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67038\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67038_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67038-5-A1\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67038-5-A1_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67038zip](http://www.adfweb.com/download/filefold/SW67038zip)

**HD67038-5-A1**

# BOX SHEET

## RS485 / Ethernet - Converter

Box Sheet for Order code: HD67038-5-A1  
Document code: BS67038-5-A1  
V1.002




**ADFweb.com srl**  
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67038-5-A1



Order code: HD67038-5-A1