



QR of Manual

[www.adfweb.com/download/
filefold/MN67038_ENG.pdf](http://www.adfweb.com/download/filefold/MN67038_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67038-Slim-2_ENG.pdf](http://www.adfweb.com/download/filefold/BS67038-Slim-2_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67038.zip](http://www.adfweb.com/download/filefold/SW67038.zip)

HD67038-Slim-2

BOX SHEET

RS232 / Ethernet - Converter

Box Sheet for Order code: HD67038-Slim-2
Document code: BS67038-Slim-2
V1.000





ADFweb.com srl

Strada Nuova, 17, IT-31010 Marenò di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67038-Slim-2



Led1:
Green
Device state

Led2:
Yellow
Serial comm.


Led3:
Yellow
Ethernet comm.

Led4:
Yellow
Not used



Connector3:
Ethernet Port
(RJ45 Plug)

Led5:
Green
Link Ethernet



Connector4:
RS232 port
Tx = Device Tx
Rx = Device Rx
SHI = Shield (to Isolated Ground)

Connector1:
Power Supply
0V = Ground
+V = Positive wire
V AC: min 8V ; max 24V
V DC: min 12V ; max 35V