

EXTERNAL LINKS

HD67083-B2-xxxMHz-0



QR of Manual

[www.adfweb.com/download/
filefold/MN67083_ENG.pdf](http://www.adfweb.com/download/filefold/MN67083_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67083-B2-0_ENG.pdf](http://www.adfweb.com/download/filefold/BS67083-B2-0_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67083.zip](http://www.adfweb.com/download/filefold/SW67083.zip)

BOX SHEET

**M-Bus Wireless / Modbus TCP slave
Converter**

Box Sheet for order code: HD67083-B2-xxxMHz-0
Document code: BS67083-B2-0
V1.002



ADFweb.com srl


Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

HD67083-B2-xxxMHz-0

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67083-B2-xxxMHz-0




Connector4:
Antenna

Led1:
Green
Device state

Led2:
Yellow
wM-Bus comm.

Led3:
Yellow
M-Bus comm.

Led4:
Yellow
Ethernet comm.



Led5:
Green
Link Ethernet

Connector3:
Ethernet Port
(RJ45 Plug)

Dip-Switch A:
-Dip1 - Functioning Mode

OFF
ON
= Normal Mode

OFF
ON
= Boot Mode

Connector2:
M-Bus master
(unpolarized)

Connector1:
Power Supply
0V = Ground
+V = Positive wire
V AC: min 15V ; max 21V
V DC: min 18V ; max 35V

Order code: HD67083-B2-xxxMHz-0