

Ethernet to RS232/RS485

MANUAL

To obtain the complete manual please go to

www.adfweb.com/download


or

www.adfweb.com/download/filefold/Ethernet_RS232_RS485_MN67120_ENG.pdf

To obtain the new version of this box sheet please go to

http://www.adfweb.com/download/filefold/BS67120_ENG.pdf

CONNECTION SCHEME



THE CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67120. To obtain this software please go to

www.adfweb.com/download

or

<http://www.adfweb.com/download/filefold/SW67120.zip>