



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67151\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67151_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67151-B2\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67151-B2_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67151.zip](http://www.adfweb.com/download/filefold/SW67151.zip)

**HD67151-B2**

# BOX SHEET

**DeviceNet Master / Modbus Slave  
Converter**

Box Sheet for Order code: HD67151-B2  
Document code: BS67151-B2  
V1.002




**ADFweb.com srl**  
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67151-B2



Order code: HD67151-B2