

Modbus Slave / SNMP Manager - Converter


To obtain the complete manual please go to

www.adfweb.com/download/filefold/MN674-A010_ENG.pdf

To obtain the new version of this box sheet please go to

www.adfweb.com/download/filefold/BS674-A010-2-E7x_ENG.pdf

CONNECTION SCHEME:



CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW674-A010.

To obtain this software please go to

www.adfweb.com/download/filefold/SW674-A010.zip

ADFweb.com s.r.l.
www.adfweb.com
info@adfweb.com
support@adfweb.com

Manual



Box-Sheet



Software

