

EXTERNAL LINKS

HD674-A034-E4x-xx



QR of Manual

[www.adfweb.com/download/
filefold/MN674-A034_ENG.pdf](http://www.adfweb.com/download/filefold/MN674-A034_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS674-A034-E4x_
ENG.pdf](http://www.adfweb.com/download/filefold/BS674-A034-E4x_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW674-A034.zip](http://www.adfweb.com/download/filefold/SW674-A034.zip)

HD674-A034-E4x-xx

BOX SHEET

DMX / BACnet/IP Master Converter

Box Sheet for Order code: HD674-A034-E4x-xx
Document code: BS674-A034-E4x
V1.000



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD674-A034-E4x-xx

Connector3:

RS485 port

+ = Positive wire
- = Negative wire
Shl = Shield (to Isolated Ground)



Connector2:

Ethernet Port
(RJ45 Plug)


Connector1:

Power Supply port

0V = Ground
+V = Positive wire

V AC: min 8V ; max 26V

V DC: min 10V ; max 40V



Connector4:

USB port

Led 1:

Green
Device State

Led 2:

Green
BACnet comm.

Led 3:

Yellow
USB link

Led 4:

Green
DMX comm.



Order code: HD674-A034-E4x-xx