

# CANopen / Modbus TCP Slave - Converter


To obtain the complete manual please go to

[www.adfweb.com/download/filefold/MN67425\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67425_ENG.pdf)

To obtain the new version of this box sheet please go to

[www.adfweb.com/download/filefold/BS67425-E4x\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67425-E4x_ENG.pdf)

## CONNECTION SCHEME:



## CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67425.

To obtain software please go to

[www.adfweb.com/download/filefold/SW67425.zip](http://www.adfweb.com/download/filefold/SW67425.zip)

ADFweb.com s.r.l.  
 www.adfweb.com  
 support@adfweb.com

Manual



Box-Sheet



Software

