



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67603\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67603_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67603-485-A1\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67603-485-A1_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67603.zip](http://www.adfweb.com/download/filefold/SW67603.zip)

**HD67603-485-A1**

# BOX SHEET

## PROFINET / Modbus Slave - Converter

Box Sheet for Order code: HD67603-485-A1  
Document code: BS67603-485-A1  
V1.003




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Marenco di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67603-485-A1



Order code: HD67603-485-A1