

EXTERNAL LINKS

HD67622-422-A1



QR of Manual

[www.adfweb.com/download/
filefold/MN67622_ENG.pdf](http://www.adfweb.com/download/filefold/MN67622_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67622-422-A1_ENG.pdf](http://www.adfweb.com/download/filefold/BS67622-422-A1_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67622.zip](http://www.adfweb.com/download/filefold/SW67622.zip)

HD67622-422-A1

BOX SHEET

S7comm / Modbus Slave Converter

Box Sheet for Order code: HD67622-422-A1

Document code: BS67622-422-A1

V1.000




ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67622-422-A1



Order code: HD67622-422-A1