

BACnet PTP slave / PROFINET slave - Converter


To obtain the complete manual please go to:

www.adfweb.com/download/filefold/MN67679_ENG.pdf

To obtain the new version of this box sheet please go to:

www.adfweb.com/download/filefold/BS67679-PTP-A1_ENG.pdf

CONNECTION SCHEME:



CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67679. To obtain this software please go to:

www.adfweb.com/download/filefold/SW67679.zip

ADFweb.com s.r.l.
www.adfweb.com
support@adfweb.com

Manual



Box-Sheet



Software

