



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67865\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67865_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67865-IP-A1-4A\\_  
ENG.pdf](http://www.adfweb.com/download/filefold/BS67865-IP-A1-4A_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67865.zip](http://www.adfweb.com/download/filefold/SW67865.zip)

# BOX SHEET

IO-Link / Bacnet Slave – Converter

Box Sheet for Order code: HD67865-IP-A1-4A

Document code: BS67865-IP-A1-4A

V1.000




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Marenco di Piave, Treviso - Italy

# CONNECTION SCHEME

Order code: HD67865-IP-A1-4A



Order code: HD67865-IP-A1-4A