



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67871\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67871_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67871-A1-2B\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67871-A1-2B_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67871.zip](http://www.adfweb.com/download/filefold/SW67871.zip)

**HD67871-A1-2B**

# BOX SHEET

**IO-Link / Ethernet/IP slave – Converter**

Box Sheet for Order code: HD67871-A1-2B

Document code: BS67871-A1-2B

V1.000




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67871-A1-2B



Order code: HD67871-A1-2B