

# PROFIBUS Slave / MQTT – Converter


To obtain the complete manual please go to:

[www.adfweb.com/download/filefold/MN67951\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67951_ENG.pdf)

To obtain the new version of this box sheet please go to:

[www.adfweb.com/download/filefold/BS67951-B2\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67951-B2_ENG.pdf)

## CONNECTION SCHEME:



## CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67951. To obtain this software please go to:

[www.adfweb.com/download/filefold/SW67951.zip](http://www.adfweb.com/download/filefold/SW67951.zip)

ADFweb.com S.r.l.  
www.adfweb.com  
support@adfweb.com

Manual



Box-Sheet



Software

