

EXTERNAL LINKS

HD67B84-A1



QR of Manual

[www.adfweb.com/download/
filefold/MN67B84_ENG.pdf](http://www.adfweb.com/download/filefold/MN67B84_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67B84-A1_ENG.pdf](http://www.adfweb.com/download/filefold/BS67B84-A1_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67B84.zip](http://www.adfweb.com/download/filefold/SW67B84.zip)

HD67B84-A1

BOX SHEET

PROFINET Master / Ethernet - Converter

Box Sheet for Order code: HD67B84-A1
Document code: BS67B84-A1
V1.100



ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67B84-A1

Dip-Switch A:

-Dip1 - Functioning Mode



= Normal



= Boot



- LED1 ON
- LED2 MT
- LED3 BF
- LED4 SF

- LED5 Ethernet1 Tx
- LED6 Ethernet2 Tx



PROFINET Master / Ethernet - Converter
HD67B84-A1
www.ADFweb.com

+V 0V
Power Supply
8...24V AC
or
12...35V DC

Dip-Switch A

Date Code: 04. 20 C.S.: B278 MAC: 10-64-E2-08-23-FF
Serial Nr.: I2421



Connector1:

Power Supply port

0V = Ground
+V = Positive wire

V AC: min 8V ; max 24V
V DC: min 12V ; max 35V

Led1:
Green
ON

Led2:
Yellow
MT

Led3:
Red
BF

Led4:
Red
SF

Led5:
Green
Ethernet1 Tx

Connector3:
Ethernet1 port
(RJ45 Plug)

Led6:
Green
Ethernet2 Tx

Connector4:
Ethernet2 port
(RJ45 Plug)

Rail DIN
Clamp

Order code: HD67B84-A1