

## EXTERNAL LINKS

HD67D20-xxxMHz-B2



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67D20\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67D20_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67D20-xxxMHz-B2\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67D20-xxxMHz-B2_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67D20.zip](http://www.adfweb.com/download/filefold/SW67D20.zip)

HD67D20-xxxMHz-B2

# BOX SHEET

LoRaWAN / CANopen Converter

Box Sheet for Order code: HD67D20-xxxMHz-B2

Document code: BS67D20-xxxMHz-B2

V1.000




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67D20-xxxMHz-B2



Order code: HD67D20-xxxMHz-B2