

## EXTERNAL LINKS

HD67D25-xxxMHz-B2



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67D25\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67D25_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67D25-xxxMHz-B2\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67D25-xxxMHz-B2_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67D25.zip](http://www.adfweb.com/download/filefold/SW67D25.zip)

HD67D25-xxxMHz-B2

# BOX SHEET

LoRaWAN / EtherNet/IP slave  
Converter

Box Sheet for Order code: HD67D25-xxxMHz-B2  
Document code: BS67D25-xxxMHz-B2  
V1.000





**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67D25-xxxMHz-B2



Order code: HD67D25-xxxMHz-B2