

## EXTERNAL LINKS

HD67F05-2-B2-915MHz



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67F05\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67F05_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67F05-2-B2-915MHz\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67F05-2-B2-915MHz_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67F05.zip](http://www.adfweb.com/download/filefold/SW67F05.zip)

# BOX SHEET

## LoRaWan Gateway / Serial Converter

Box Sheet for Order code: HD67F05-2-B2-915MHz  
Document code: BS67F05-2-B2-915MHz  
V1.000



**ADFweb.com srl**


Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

HD67F05-2-B2-915MHz

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67F05-2-B2-915MHz



Order code: HD67F05-2-B2-915MHz