

EXTERNAL LINKS

HD67F38-B2-868MHz



QR of Manual

[www.adfweb.com/download/
filefold/MN67F38_ENG.pdf](http://www.adfweb.com/download/filefold/MN67F38_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67F38-B2-868MHz_ENG.pdf](http://www.adfweb.com/download/filefold/BS67F38-B2-868MHz_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67F38.zip](http://www.adfweb.com/download/filefold/SW67F38.zip)

HD67F38-B2-868MHz

BOX SHEET

LoRaWan Gateway / OPC UA server
Converter

Box Sheet for Order code: HD67F38-B2-868MHz
Document code: BS67F38-B2-868MHz
V1.000




ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67F38-B2-868MHz



Order code: HD67F38-B2-868MHz