

## EXTERNAL LINKS

HD67F41-B2-868MHz



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67F41\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67F41_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67F41-B2-868MHz\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67F41-B2-868MHz_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67F41.zip](http://www.adfweb.com/download/filefold/SW67F41.zip)

HD67F41-B2-868MHz

# BOX SHEET

LoRaWan Gateway / SNMP Agent  
Converter

Box Sheet for Order code: HD67F41-B2-868MHz  
Document code: BS67F41-B2-868MHz  
V1.000




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67F41-B2-868MHz



Order code: HD67F41-B2-868MHz