



QR of Manual

[www.adfweb.com/download/
filefold/MN67001_ENG.pdf](http://www.adfweb.com/download/filefold/MN67001_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67001_ENG.pdf](http://www.adfweb.com/download/filefold/BS67001_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67001.zip](http://www.adfweb.com/download/filefold/SW67001.zip)

HD67001

BOX SHEET

CanOpen to Modbus RTU Master

Box Sheet for order code: HD67001
Document code: BS67001
V1.003



ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com


CONNECTION SCHEME

Order code: HD67001

Jumper3: Boot mode

 = Yes Jumper
Boot Mode

 = No Jumper
Normal Mode



Jumper2: Termination Modbus Line

 = Open  = 220 ohm

Connector3: Modbus on RS485 Port 1

S1 = Shield/GND(*)
B1 = Negative wire
A1 = Positive wire

Connector2: CANopen

H = High wire
S = Shield
L = Low wire

Jumper1: Termination CANopen Line

 = Open  = 120 ohm

Connector1: Power Supply

0V = Ground
+V = Positive wire
12/18 VAC - 4 VA
12/24 VDC - 4 Watt

Led2:
Green
RUN

Led1:
Yellow
Blink quickly:
Boot Mode


Connector4: Port RS232 (D-SUB9-Male)

PIN2 = RX
PIN3 = TX
PIN5 = GND

Used for:
A) Programming Port
B) Modbus on RS232

To connect the device to the COM port of a PC in order to set it. You have to use the programming cable AC34107.

Or a cable made as showed here:



Led3:
Green
Not used

Order code: HD67001