



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67613\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67613_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67613-A1\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67613-A1_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67613.zip](http://www.adfweb.com/download/filefold/SW67613.zip)

**HD67613-A1**

# BOX SHEET

## PROFINET / SNMP - Converter

Box Sheet for Order code: HD67613-A1  
Document code: BS67613-A1  
V1.001



**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67613-A1

**Dip-Switch A:**  
-Dip1 - Functioning Mode

 = Normal     = Boot



LED1 ON  
 LED2 MT  
 LED3 BF  
 LED4 SF

LED5 Ethernet1 Tx  
**ETHERNET 1**

LED6 Ethernet2 Tx  
**ETHERNET 2**

**Dip-Switch A**  
 ON

PROFINET / SNMP - Converter  
**HD67613-A1**  
www.ADFweb.com    Q.n. - - - -

Date Code: 14. 20    C.S.: B278    MAC: 10-64-E2-07-37-23    Serial Nr.: C3187

+V 0V  
Power Supply  
8...24V AC  
or  
12...35V DC

CE  
RoHS

Rail DIN  
Clamp

**Led1:**  
Green  
ON

**Led2:**  
Yellow  
MT

**Led3:**  
Red  
BF

**Led4:**  
Red  
SF

**Connector3:**  
Ethernet1 Port  
(RJ45 Plug)

**Led6:**  
Green  
Ethernet2 Tx

**Connector4:**  
Ethernet2 Port  
(RJ45 Plug)

**Connector1:**  
Power Supply port  
0V = Ground  
+V = Positive wire  
V AC: min 8V ; max 24V  
V DC: min 12V ; max 35V

Order code: HD67613-A1